



GENERAL NOTES

1. PLACE PAVERS IN PATTERNS PER CITY OF FRANKLIN STREETSCAPE PLANS. PLACE PAVERS WITH HAND TIGHT JOINTS NOT TO EXCEED 1/8" (MIN 1/16"). SAW CUT PAVERS AS NEEDED TO MAINTAIN ABOVE JOINT TOLERANCES.
2. DO NOT USE FILLERS TO FILL JOINT VOIDS OF EXCESSIVE WIDTH. RESET AND SAW CUT PAVERS AS REQUIRED TO ELIMINATE EXCESSIVE JOINT WIDTHS.
3. 4" THK POURED CONCRETE BASE ON ALL SIDEWALKS AND 6" THK PURED CONCRETE BASE ON ALL DRIVEWAYS.
4. THIS DETAIL TO BE USED IN DOWNTOWN FRANKLIN GATEWAY CORRIDORS AND CONNECTOR STREETS.

N.T.S



HISTORIC
FRANKLIN
TENNESSEE

2 1/4" THICK BRICK PAVERS ON CONCRETE BASE

CITY OF FRANKLIN

NOT TO SCALE

CITY
ENGINEER:

Paul P. Hoyle

DATE:

7/1/2021

DWG. NO.

SS-2