



NOTES

1. EXPANSION JOINTS:
 - A. RUBBERIZED EXPANSION JOINT FILLER (AASHTO M153, TYPE 1)
2. 1/2" THICK EXPANSION JOINTS SHALL BE PLACED AS FOLLOWS:
 - A. TRANSVERSE TO SIDEWALK AT 25 TO 30 FEET APART DEPENDING ON TRANSVERSE JOINT MARKINGS
 - B. TRANSVERSE TO SIDEWALK AT CURB EXPANSION JOINTS WHERE SIDEWALK IS BUILT DIRECTLY AGAINST CURB
 - C. BETWEEN CURB AND SIDEWALK WHERE SIDEWALK IS BUILT DIRECTLY AGAINST CURB
 - D. AT ABUTTING RIGID DRIVEWAYS OR OTHER SIDEWALKS
 - E. AT CHANGES IN SIDEWALK DIRECTION, INCLUDING AT STREET CORNERS AND AT CURVED SECTIONS
 - F. AT OTHER PLACES WHERE STRESSES MAY DEVELOP
3. 1" THICK EXPANSION JOINTS SHALL BE PLACED WHERE SIDEWALK ABUTS CIRCULAR CURBS, BUILDINGS, AND WALLS.

SIDEWALK EXPANSION JOINT

DWG. NO.

RP-10



HISTORIC
FRANKLIN
TENNESSEE

CITY OF FRANKLIN

NOT TO SCALE

CITY
ENGINEER:

Paul P. Hoyle

DATE:

7/1/2023